



GRANDSTREAM GRP2616

MENU CONFIGURATION FLOW CHART

To display MENU options, press the circular button in the center of the Arrow Buttons

